



HANOVER PROGRAMMING

UNIT:



DEST PROGRAM:

To Input Destination Code:

Press [D] to display "DESTINATION & ROUTES", then type in route code into the system, press [ENT].

TO CHANGE CODES, PRESS [DEST A] OR [DEST]. YOU DO NOT NEED TO [ENTER]

P/R PROGRAM:

To Input P/R Code:

Press [I] to display "INFORMATION", then type in the P/R code into the system, press [ENT].

To Clear P/R:

Press [I], use code 0, then [ENTER]

REVISED: 5/20/2024

M:\Operations\Dispatch + SA\Handy References\Bus Operations Booklets