



LUMINATOR PROGRAMMING

UNIT:



DEST PROGRAM:

To Input DEST A or DEST B:

Press [DEST A] or [DEST B], enter the route code, then press [ENTER]. The system will display "VERIFY STOP", press [ENTER]
If the code is incorrect it will display "EXCEEDED RANGE NEW DESTINATION" or "NO STOP ANNOUNCEMENTS FOR THIS DESTINATION". In either case, confirm the code is correct and attempt to retype the code into the system.

TO CHANGE CODES, PRESS [DEST A] OR [DEST]. YOU DO NOT NEED TO [ENTER]

P/R PROGRAM:

To Input P/R:

Press [P/R], type in the P/R code into the system, then press [ENTER]

To Clear P/R:

Press [P/R], use code 0, then [ENTER]

REVISED: 5/20/2024

M:\Operations\Dispatch + SA\Handy References\Bus Operations Booklets